
Rearview camera (Rear Assist) , (KA2) from April 2015



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.





Rearview camera system control module, Rearview camera

- J772 Rearview camera system control module
- J794 Information electronics control module 1
- R189 Rearview camera
- SB Fuse panel B
- ST1 Fuse panel 1
- SB10 Fuse 10 (on fuse panel B)
- T2pb 2-pin connector
- T8bg 8-pin connector
- T12c 12-pin connector
- T12g 12-pin connector
- 51 Ground connection in luggage compartment, right
- 383 Ground connection 18 (in main wiring harness)
- (386) Ground connection 21 (in main wiring harness)
- 654 Ground connection on right D-pillar
- B279 Positive connection 3 (15a) (in main wiring harness)
- * pre-wired component
- *2 Refer to applicable wiring diagram for fuse positions
- *3 Avant

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

sw = black
ro = red
rt = red
br = brown
gn = green
bl = blue
gr = grey
li = lilac
vi = lilac

= white


= white = black = red = red

= brown = green = blue = grey = lilac

= lilac = yellow

= pink

= orange



Rearview camera system control module

J533 Data bus on board diagnostic interface

J772 Rearview camera system control module

T8bg 8-pin connector T32b 32-pin connector

(B108) CAN bus extended high connection 1 (in main wiring harness)

(B109) CAN bus extended low connection 1 (in main wiring harness)